

**DR<sup>®</sup>** LAWN AERATOR




DR AER800MN PARTS LIST





**Schematic – FRAME AND DRIVE ASSEMBLY**




## Parts List – CRANKSHAFT AND TINE ASSEMBLY

**NOTE:** Part numbers listed are available through DR Power Equipment.

<u>Ref#</u>	<u>Part#</u>	<u>Description</u>	<u>Ref#</u>	<u>Part#</u>	<u>Description</u>
1	27646	Crankshaft	13	10145	Bolt, HCS, 1/4-20 X 1-1/2", GR5, ZP
2	27655	Bearing, Nylon, Split	14	11073	Nut, Nylon Lock, 1/4-20, ZP
3	27651	Rod, Tine	15	27643	Plate, Bearing
4	27652	Cap, Tine Rod	16	27644	Bearing, Flange, 1" Bore
5	10189	Grease Fitting 1/4-28, Straight	17	27645	Bolt, FHCS, 5/16-18 X 1.25", Alloy
6	27653	Tine, 5/8"	18	12321	Bolt, HCS, 5/16-18 X 3/4", GR5, ZP
7	27654	Nut, Jam, 5/8-11, GR5, ZP	19	11158	Bolt, HCS, 5/16-18 X 1", ZP
8	10147	Bolt, HCS, 5/16-18 X 2-1/4", GR5, ZP	20	27650	Nut, Pivot
9	11241	Washer, Flat, 5/16", USS, ZP	21	27647	Arm, Tine Position, LH
10	11076	Nut, Nylon Lock, 5/16-18, ZP	22	27648	Arm, Tine Position, RH
11	27649	Plate, Tine Position	23	13443	Bolt, HCS, 5/16-18 X 1-1/2", GR5, ZP
12	27669	Cable, Tine Position			

**Schematic – CRANKSHAFT AND DRIVE ASSEMBLY**





**Schematic – HANDLEBAR ASSEMBLY**

